



**LAPOR 1**

**DEP RWY 19:** Ascender en R187 FAG VOR/DME, cruzar D23 FL60 o superior, cruzar D45 FL110 o superior para interceptar AWY, luego según autorización ATC.

**TAKE-OFF RWY 19:** Climb on R187 FAG VOR/DME, cruzar D23 at or above FL60, cross D45 at or above FL110 to intercept AWY, then according to ATC clearance.

DASA / SECCION AIS-MAP