



CONCEPCION	
APP	120.5
TWR	118.1

Nivel de Transición by ATC
 Transition Level by ATC

No se ajusta a escala / Not to scale

STAR LITRE 5

En D35 CAR VOR/DME abandonar AWY para interceptar R197 (TR017°) CAR VOR/DME. Cruzar D25 FL50 o superior, cruzar LAGAS INT (R197 / D15) 3500FT o superior, luego según autorización ATC.

At D35 CAR VOR/DME leave AWY to intercept R197 (TR017°) CAR VOR/DME. Cross D25 at or above FL50, cross LAGAS INT (R197 / D15) at or above 3500FT, then according to ATC clearance.

DASA / SECCION AIS-MAP